Wi-Fi15-2
Wi-Fi (Wireless LAN) 15-2
Registering Private Access Points 15-3
Using Public Wireless LAN Services 15-6
Infrared15-7
Transferring Files via Infrared 15-8
IC Transmission15-10
Transferring Files via IC Transmission
15-11
Bluetooth® 15-12
Transferring Files via Bluetooth® 15-13

External Device Connection Connecting PC or Blu-ray Disc	15-16
Recorder	15-16
Backup	15-17
Basics	15-17
Backup & Restore	15-18
S! Addressbook Back-up (SAB)	15-19
About SAB	15-19
Using Sync Commands	15-21
Additional Functions	15-22
Troubleshooting	15-26


Connectivity & File Backup



# Wi-Fi (Wireless LAN)

941SH supports wireless LAN (hereafter "Wi-Fi") that enables Internet connection via private Wi-Fi network, public wireless LAN service, etc. Handset connects to the Internet via Wi-Fi automatically whenever possible, allowing high-speed communication without switching networks.

Subscription to Keitai Wi-Fi is required to use Yahoo! Keitai and PC Site Browser over Wi-Fi.



# Service Usage Outline

Private Wi-Fi network Public wireless LAN service

Prepare devices. contract with ISP, etc. Subscribe to service, etc.

Register access point on handset

Connected to Wi-Fi within access point range

#### **Registering Access Points**

- Save access point information to handset to use Wi-Fi.
  - Handset connects to registered access points automatically.
- Access point search may take some time depending on the number of registered access points.

#### Important Wi-Fi Usage Note

• Depending on signal conditions, connection may automatically switch from Wi-Fi to 3G incurring packet transmission fees; set confirmation to appear as needed.

#### **Advanced**



🎐 🌑 Disabling Wi-Fi 🌑 Showing confirmation when switching networks 🌑 Protecting access point information by Handset Code 🜑 Specifying channel range Opening access point properties Opening Wi-Fi-related handset properties (P.15-22)


# **Registering Private Access Points**

- Broadband connection, ISP subscription and Wi-Fi access point are required.
- To connect to corporate access points, consult the system administrator for settings.
- Configure settings on Wi-Fi access points beforehand. (For details, see the access point guide.)
- Access point information (SSID, authentication method, encryption method, security key, etc.) is unique to each access point. Check it beforehand.

# Using AOSS<sup>™</sup> or WPS

AOSS<sup>™</sup> and WPS are systems/standards for easy access point registration and security configuration; available on compatible Wi-Fi access points.

Using AOSS™





Wi-Fi Menu



# Create Profile



Create Profile Menu

 A confirmation appears if no access point is registered. Read the message and tap OK.



 If not using Yahoo! Keitai or PC Site Browser over Wi-Fi, tap *Check* before



- Follow onscreen instructions.
- To cancel, tap Cancel.
- Handset connects to Wi-Fi upon completion of registration (Switch On/Off: On).





# **Using WPS**


Example: Push Button Configuration (PBC) method

- In Create Profile menu, Create by WPS
  - If not using Yahoo! Keitai or PC Site Browser over Wi-Fi, tap Check before 2.
- Start
  - Follow onscreen instructions.
  - To cancel, tap Cancel.
  - Handset connects to Wi-Fi upon completion of registration (Switch On/Off: On).

#### **Using PIN Method**

- Enter an eight-digit number (PIN) generated by handset into the access point. After ①, Switch ⇒ PIN entry ⇒ Start
  - **⇒** Enter number on Display into access point **→** OK

**Access Point Search** 





- To cancel, tap Cancel.
- Select access point
- Enter corresponding security key **→** Done
- Use or Not Use





- Yes
- Handset connects to Wi-Fi (Switch On/Off: On).

#### If Encryption Method is WEP

• After (3), authentication method selection window opens. Select a method according to the access point.



## Registering Access Points Manually

Check access point information beforehand.

# **Major Items**

#### Access Point Profile

Profile Name	Enter a name
	Enter the same SSID as the access point

## Security

	Authentication Method	Supported authentication methods vary by access point; set accordingly
	Encryption Method	Supported encryption methods vary by authentication method; set according to access point
•	Security Key	Enter the security key (also called "encryption key," "network key" or "passphrase") set on the access point

# **Entering Information**

Example: Authentication Method is WPA-PSK or WPA2-PSK.

In Create Profile menu, Manual



- Profile Name 

  ◆ Enter name Done
- SSID → Enter SSID → Done
- Security



Security Menu

- Authentication Method **→** Select method
- Encryption Method **⇒** Select method
- Security Key 

  ▶ Enter security key **→** Done
- OK **⇒** Save
- Yes
  - Handset connects to Wi-Fi (Switch On/Off: On).

If Authentication Method is Open System

- & Encryption Method is No Authentication · Omit security key entry.
- If Encryption Method is WEP
  - Done → OK → From 3



# **Using Public Wireless LAN Services**

- Subscription with the corresponding service provider, etc. is required.
- Access point information (SSID, authentication method, encryption method, security key, etc.) is unique to each access point. Check it beforehand.
- Subscription to Keitai Wi-Fi provides access to BB mobilepoint service. For more about BB mobilepoint, see SOFTBANK TELECOM Website (P.17-23).

#### **Using BB mobilepoint**

- MENU → Tools →
  Connectivity tab → Wi-Fi
- Create Profile



Create Profile Menu

 A confirmation appears if no access point is registered. Read the message and tap OK.





- Password ⇒ Enter password ⇒ Done
- Save
- Yes
  - Handset connects to Wi-Fi (Switch On/Off: *On*).

# Using Other Public Wireless LAN Services

- Check public wireless LAN service information beforehand.
- Connection to some public wireless LAN services may not be possible.
- In Create Profile menu,

  Manual
- Complete fields

   For details, see P.15-5 "F
  - For details, see P.15-5 "Entering Information."
- Advanced Settings 
  WISPr Settings
- User ID ⇒ Enter ID ⇒ Done
- Password ⇒ Enter password ⇒ Done
- Switch On/Off → On
- OK ⇒ OK ⇒ Save
- 🧿 Yes
  - Handset connects to Wi-Fi (Switch On/Off: *On*).



Wirelessly transfer files between 941SH and compatible devices.

941SH supports IrSimple<sup>™</sup> high-speed wireless communications protocol; exchange large image files instantly with compatible mobile phones, printers, etc.

#### Transferable Files

Phone Book	Received Msg.
Calendar	Sent Messages
Tasks	Drafts
Notepad	Templates (Messaging)
Bookmarks	Data Folder


- Copy/forward protected files are not transferable.
   Some files may not be transferable; some
- Some files may not be transferable; some settings may be lost, or files may not be saved properly. For details, see
   "Troubleshooting" at the end of this chapter.

# **Getting Started**

# Infrared Precautions

Align Infrared Ports of both devices.

• Handset cannot receive connection requests during Software Update.



- Do not place objects between devices.
- Keep Infrared Ports aligned during transfer.
- Do not look into Infrared Port during infrared transmissions. Eyesight may be affected.
- 941SH complies with IrMC 1.1, however, some files may not transfer properly.

# Transfer Options

One File Transfer	Transfer single files
All File Transfer	Transfer all files by function
IrSS Transfer	Exchange single image files with compatible devices at high speed

- Some transfer options may be unavailable depending on file type.
- Transfer Memory Card files one by one.

#### **Authorization Code**

 Four-digit code required for Infrared transfers. All File Transfers possible when codes match. (Authorization Code is changeable for each transfer.)



# Transferring Files via Infrared

## **Receiving Files**

MENU → Tools → Connectivity tab → Infrared



- Switch On/Off → On(3 min.)
  - Infrared is activated.
  - Handset receives files if sent within three minutes.
  - Handset must be in Standby to accept connection requests.
  - Alternatively, Long Press in Standby to toggle Infrared on/off.
- Connection request arrives



Request Window

- Perform subsequent operations
  - To cancel transfer, tap Cancel.
- Subsequent Operations
- One File Transfer Yes → Yes
  - If storage media confirmation appears, select media.
- All File Transfer (Adding Files)

  Yes → Enter Handset Code → OK →

  Enter Authorization Code → OK →

  As New Items
- All File Transfer (Overwriting Existing Files)

  Yes → Enter Handset Code → OK → Enter Authorization Code → OK → Delete All & Save → Yes
  - For Phone Book, My Details except handset phone number is overwritten as well
- IrSS Transfer Yes
  - Files are saved to Data Folder (Pictures).



#### **Advanced**

Sending images via IrSS Transfer without reducing size (P.15-23)

#### Sending Files

One File Transfer

Example: Phone Book entry





Via Infrared



- Yes → Transfer starts
  - When complete, entry search window returns.

All File Transfer

- MENU → Tools → Connectivity tab 

  → Infrared
- Send All
- Yes 

  ▶ Enter Handset Code → OK



- Select item ( /√) ▶ Complete selection **→** Send
- Enter Authorization Code ▶ OK ⇒ Transfer starts ⇒ OK

#### Sending Phone Book

• In . Picture transfer confirmation appears; tap Yes or No.

- Sending JPEG Images at High Speed
- Pictures or DCIM For DCIM, select a folder.
- Highlight image 

  ▶ Long Touch Hold:Irss



- Yes or No → Transfer starts
  - Images may be reduced automatically before transfer depending on the size.
  - When complete, file list returns.
  - Transfers are one-way; end even if files are not received.



# **IC Transmission**

Wirelessly transfer files between 941SH and compatible devices.

- For transferable files, see P.15-7.
- Cancel IC Card Lock beforehand
- Disconnect Headphones, USB Cable and AC Charger beforehand.

# **Getting Started**

# **IC Transmission Precautions**

Align  $olimitsize \subseteq \text{logos of both devices.}$ 



Keep 2 logos aligned during transfer.

# **Transfer Options**

One File Transfer	Transfer single files
All File Transfer	Transfer all files by function

- Some transfer options may be unavailable depending on file type.
- Transfer Memory Card files one by one.

#### **Authorization Code**

• Four-digit code required for IC transfers. All File Transfers possible when codes match. (Authorization Code is changeable for each transfer.)



# Transferring Files via IC Transmission

## **Receiving Files**

Connection request arrives



Request Window

- Handset must be in Standby to accept connection requests.
- Perform subsequent operations
  - To cancel transfer, tap Cancel.
- **Subsequent Operations**
- One File Transfer Yes 

  → Yes
  - If storage media confirmation appears, select media
- All File Transfer (Adding Files) Enter Authorization Code → OK → As New Items

■ All File Transfer (Overwriting **Existing Files)** 

Enter Authorization Code → OK →

Delete All & Save → Yes

• For Phone Book, My Details except handset phone number is overwritten as well.

#### Sending Files

One File Transfer

Example: Phone Book entry





Via IC Transmission



Yes 

Transfer starts

**All File Transfer** 

MENU → Tools → Connectivity tab 

→ IC **Transmission** 



IC Transmission Menu


- Send All
- ◆ OK



- Select item ( /√) ▶ Complete selection **⇒** Send
- Enter Authorization Code **▶** OK ⇒ Transfer starts ⇒ OK

#### Sending Phone Book

appears; tap Yes or No.



# Bluetooth®

Wirelessly transfer files/data between 941SH and compatible devices (watches, handsfree devices, etc.).

- For transferable files, see P.15-7.
- 941SH supports simultaneous connection with two devices. (May be unavailable depending on the device type.)
- Bluetooth® connection may not be possible with some Bluetooth® devices.
  - Handset shall be connected to certified Bluetooth<sup>®</sup> devices that meet the specification standards developed by Bluetooth SIG.
  - Data transfers may fail depending on characteristics or specifications of the certified Bluetooth® devices.
- Noise may interfere with wireless or handsfree conversations.
- TV audio is supported only on SCMS-T DRM scheme compliant Bluetooth<sup>®</sup> devices.

## **Getting Started**

# Bluetooth® Precautions

Check transmission range of your Bluetooth® device to use with handset properly.

Maximum transmission range for transfers between 941SH handsets is ten meters.

(Bluetooth® connection/transfer rate may vary depending on conditions.)

#### Important Handsfree Device Usage Note

- Handle call operations on the device in use.
   Bluetooth® Watches
- Compatible Bluetooth® watches support these functions:
  - Time Correction Alarm Notice
  - News Notice
- otice Mail Notice
  Shutter Mode Settings
  - Remote Shutter
     Quick Silent
- Caller ID Notice
- Hold Calls
- Operator Notice
- For details about functions/operations, see the Bluetooth<sup>®</sup> watch guide.

# Sender Search for devices Select device Request connection (Enter Authorization Code) Accept Accept Accept Accept Accept Accept Accept Accept

#### **Authorization Code**

 4 to 16-digit code required for Bluetooth<sup>®</sup> connections. Pairing possible when codes match.

Connection complete

- For handsfree devices, enter specified Authorization Code.
- Authorization Code entry may not be required depending on the other device.



- 🆑 🌑 Cloaking handset to avoid connection requests 🌑 Setting idle time after which Bluetooth 🖱 is canceled 🜑 Switching audio output to wireless device
  - ■Changing Bluetooth® name for handset ■Opening Bluetooth®-related handset properties (And more on P.15-23 15-24)
  - Synchronizing Bluetooth® watch with handset Enabling/disabling Bluetooth® watch responses (P.15-24)

# Transferring Files via Bluetooth®

#### Activating Bluetooth®

MENU → Tools → Connectivity tab 

→ Bluetooth



Bluetooth Menu

Switch On/Off ⇒ On



- Bluetooth<sup>®</sup> is activated.
- Handset must be in Standby to accept connection requests from unpaired handsfree devices, etc.
- Alternatively, Long Press in Standby to toggle Bluetooth® on/off.

# Connecting Bluetooth® Devices

# **Device Search & Pairing**

Activate Bluetooth® on devices to be paired with.

In Bluetooth menu, Add Device



 To disable confirmation, tap Uncheck before 6.



# OK

- Found devices are listed after search.
- To cancel search, tap Cancel.


Select device If a confirmation appears, tap Yes.

Enter the same **Authorization Code for** handset and the other device **→** OK **→** Pairing complete

- On the other device, complete code entry within 30 seconds.
- Authorization Codes are not necessary for paired devices.

Connecting Bluetooth® Specification Ver. 2.1 Compliant Devices In ②. Yes → Pairing complete

■ If the other device is a keyboard, follow onscreen instructions





# **Connecting Paired Devices**

In Bluetooth menu, Paired **Devices** 



Paired Device List



- If handset is already connected to another device, disconnection confirmation may appear; tap Yes.
- The device is connected and 🗸 (preferred) appears.

# **Accepting Connection Requests**

Follow these steps to accept connection requests from unpaired devices:

**Connection request arrives** 



Request Window

Yes



- Enter the same **Authorization Code as** sender's **→** OK
  - Complete code entry within 30 seconds.

#### Connecting Bluetooth® Specification Ver. 2.1 Compliant Devices

In 🕙, Yes

■ If the other device is a keyboard, follow onscreen instructions.



Follow the steps below to exchange files with paired devices.

- For transferable files, see P.15-7.
- When requested, enter Authorization Code.
- Receiving Files
- Connection request arrives



- Perform subsequent operations
  - To cancel transfer, tap Cancel.

- Subsequent Operations
  - One File Transfer
    - Yes 

      → Yes
    - If storage media confirmation appears, select media.
  - All File Transfer (Adding Files)
     Yes → Enter Handset Code → OK
    - → As New Items
  - All File Transfer (Overwriting Existing Files)
    - Yes 

      ► Enter Handset Code 

      OK
    - Delete All & Save → Yes
- Sending Files
- One File Transfer
  Example: Phone Book entry
- Options → Highlight entry → Options → Send Entry



Via Bluetooth

- Select device
- Yes → Transfer starts

   When complete entry search
  - When complete, entry search window returns
- All File Transfer
- In Bluetooth menu, Send All
- Select device Yes
- Enter Handset Code **→** OK




- Select item (□/✓) →
  Complete selection → Send
  → Transfer starts → OK
- Sending Phone Book
- In ②, Picture transfer confirmation appears; tap Yes or No.



# Connecting PC or Blu-ray Disc Recorder

# **Connecting PC**



Connect handset to a PC via USB Cable to access Memory Card from the PC without removing card from handset. USB Cable may be purchased separately.

Connect handset to a PC via
USB Cable



- Mass Storage
  - Use PC to access Memory Card.
- Cancel → Yes →
  Connection ends
  - Disconnect USB Cable.

#### If Menu in ① Does Not Appear

- Follow these steps:
- MENU → Tools → Connectivity tab
  - **⇒** USB Mode **⇒** From ②
- Operations on the PC may be required; if prompted, follow onscreen instructions.

#### Utility Software (Japanese)

For more PC-related operations, download Utility Software (including USB Cable driver) from the following URL. Utility Software

http://k-tai.sharp.co.jp/download/tools/utility/

#### **Mobile Data Communication Fees**

 Using the Internet by connecting handset to PC/PDA via USB Cable or Bluetooth<sup>®</sup> may incur high charges as large-volume packet transmissions tend to occur in a short period of time.

#### Connecting Blu-ray Disc Recorder

Connect handset to a Blu-ray Disc recorder via USB Cable to transfer recorded programs to Memory Card without removing card from handset.

- Compatible only with SHARP Blu-ray Disc recorders. For details, see P.17-23
   "Compatible Blu-ray Disc Recorders."
- USB Cable may be purchased separately.

Connect handset to a
Blu-ray Disc recorder via
USB Cable



- Recorder Link
  - Transfer files from Blu-ray Disc recorder to Memory Card.
- Cancel → Yes →
  Connection ends
  - Open transferred files via Recorder Contents in TV menu or Media Plaver menu (Videos).

#### If Menu in 1 Does Not Appear

- Follow these steps:
  - MENU → Tools → Connectivity tab → USB Mode → From ②
  - Operations on the PC may be required; if prompted, follow onscreen instructions.



Back up information to Memory Card, and restore to handset as needed.

## **Supported Items**

Received Msg.

Select items to back up, or transfer all at once.

Items with \* are selectable at once via **Check Selection** in Options menu.

	•
Phone Book	Sent Messages
Calendar*	Drafts*
Tasks <sup>*</sup>	Templates (Messaging)
Bookmarks*	Contents Keys
Notepad <sup>*</sup>	Data Folder
Mail Groups*	User Dictionary

#### **Precautions**

- Not available if battery is low.
- Some items may not be transferable; some settings may be lost, or files may not transfer properly. For details, see
   "Troubleshooting" at the end of this chapter.

#### Transferring All Items

 Use blank Memory Card for Backup All Items. Do not use the card to save other files after Backup All Items; backed up content may not be restored properly.

#### **Contents Keys**

 Moving Keys to Memory Card creates a special file. Performing Backup again on the same Memory Card overwrites that file. Perform Restore beforehand.



# **Backup & Restore**

#### **Handset to Memory Card**

Follow these steps to back up selected items at once:

MENU → Settings →
Phone/ tab → Backup/
Restore



Backup/Restore Menu

- Backup Selected Items 

  Enter Handset Code 

  OK
- Yes
- Select item (□/√) ⇒
  Complete selection
  - For *Phone Book*, a confirmation appears. Tap *Yes* or *No*.

- Execute → Yes
  - To cancel, tap Cancel.
- Backup complete **→** *OK* **→** *OK*

Selecting Multiple Items at Once In ②, Options ⇒ Select option ⇒ From ⑤

Selecting/Canceling All Items
In ②, Options → Check All or
Uncheck All

#### **Memory Card to Handset**

Follow these steps to restore selected items: (Restoring backed up content to handset overwrites current--with the exception of Contents Keys--handset content.)

In Backup/Restore menu,

Restore Selected Items 

Enter Handset Code 

OK

- Yes
- Select item (□/✓) →
  Complete selection
- **4** ок
  - If no file list appears, skip ahead to
- Select file
  - Repeat to complete selection.
- 🕞 ок
  - Yes ■ To cancel, tap Cancel.
- Restore complete → OK → OK

Selecting Multiple Items at Once In ⊚, Options ⇒ Select option ⇒ From ②

Selecting/Canceling All Items
In ⑤, Options ➡ Check All or
Uncheck All

Changing Restoration Method

After ③, highlight item ▶ Options ▶


Change to Add Mode or Chg. to

Overwrite Mode ▶ From ②



# **About SAB**

Back up Phone Book content in SAB; add Phone Book changes to SAB anytime. Edit SAB online via PC; add SAB changes to Phone Book anytime. Restore lost or altered Phone Book content from SAB.



- SAB requires a separate contract and basic monthly fee.
- Use SAB to add Phone Book content to a new compatible SoftBank handset: some conditions apply (P.15-20).
- Use a PC to edit SAB online.
- For more about SAB, see SoftBank Mobile Website (P.17-23).
- Synchronization incurs packet transmission fees.

#### **Auto Synchronization**

- When subscribed to SAB, Network Information retrieval activates auto synchronization (Auto Sync Settings: On, Set Frequency: After Editing Ph.Book(10 min.), Sync Mode Setting: Normal); Phone Book changes are added to SAB automatically.
- Cancel auto synchronization as needed. However, it reactivates after Network Information retrieval.

# **SAB Sync Commands & Features**

	Normal	Synchronize Phone Book and SAB <sup>1</sup>
	Sync from Client	Add Phone Book changes to SAB <sup>2</sup>
Synchronization	Backup	Export Phone Book content to SAB <sup>3</sup>
	Sync from Server	Add SAB changes to Phone Book <sup>4</sup>
	Restore	Import SAB content to Phone Book <sup>5</sup>
	Import from PC	Upload PC address book info to SAB
Edit on PC	Export to PC	Export SAB content to PC address book
	Sync Lock	Prevent synchronization from handset
	Birthday	SAB sends reminders via SMS to
	Notification	handset
Send	Email Address	Send new handset mail address to
Notice <sup>6</sup>	Notification <sup>7</sup>	specified addresses
1101100	"Disaster Message	Send emergency message board
	Board" Message	update to specified addresses
	Notification <sup>8</sup>	apadio to opcomod addioooo
Spam Filter	Tomodachi	Always accept messages from
Spain Filler	Email Filter <sup>9</sup>	mail addresses saved in SAB

<sup>&</sup>lt;sup>1</sup> If the same entry item is edited in Phone Book and SAB, SAB content is referenced.



<sup>&</sup>lt;sup>2</sup>Unrelated SAB changes remain.

<sup>&</sup>lt;sup>3</sup>Any existing SAB content is deleted.

<sup>&</sup>lt;sup>4</sup>Unrelated Phone Book changes remain.

<sup>&</sup>lt;sup>5</sup>Any existing Phone Book content is deleted.

<sup>&</sup>lt;sup>6</sup>Access this function via handset (My SoftBank; Japanese) or a PC.

<sup>&</sup>lt;sup>7</sup>Backup resets notification setting; handset address is sent to all addresses.

<sup>&</sup>lt;sup>8</sup>Backup resets notification setting; updates are not sent to any address.

<sup>&</sup>lt;sup>9</sup>Export Phone Book content to SAB beforehand.

# Service Usage Outline

## **Complete Contract**

Visit a SoftBank Shop, dial 157 from a SoftBank handset for SoftBank Mobile Customer Center, General Information or access My SoftBank (Japanese).



#### **Receive User ID & Password**

After subscription, user ID and password arrive via SMS.

• User ID and password are required to use SAB via a PC.



#### IISE SAR

Export Phone Book content to SAB.

# **Precautions**

#### Unsynchronizable Items

These Phone Book settings are lost:

- Picture, Tone/Video, Vibration
- Unintentional Phone Book or SAB Content Deletion
- When no Phone Book content exists, performing synchronization via Normal, Sync from Client or Backup deletes all SAB content.
- When no SAB content exists, performing synchronization via Normal. Sync from Server or Restore deletes all Phone Book content
- Phone Book ⇔ SAB Content Capacity Disparities

When the number of savable items varies between Phone Book and SAB entries, synchronization reflects lower limit.

■ Contract Termination

SAB content is deleted upon contract termination.


- SAB Transfers to New Handsets
- SAB-Compatible 3G Handsets SAB remains as last saved and is fully accessible.
- Other 3G Handsets SAB remains as last saved and is accessible via PC.
- V3/V4/V5/V6/V8 Series Service contract is terminated and SAB content is deleted.
- When Double Number is Active

Regardless of usage mode setting, all Phone Book content is backed up.



#### **Normal (Start Sync)**

Synchronize Phone Book and SAB via Normal.





S! Addressbook Menu



 Synchronization starts; when complete, details appear.



**Canceling Synchronization** Cancel > Yes

# Other Sync Commands

Available Commands:

Sync from Client	Add Phone Book changes to SAB
Backup	Export Phone Book content to SAB; any existing SAB content is deleted
Sync from Server	Add SAB changes to Phone Book
Restore	Import SAB content to Phone Book; any existing Phone Book content is deleted

If this is your first use of SAB (new handset), synchronization is performed via Normal regardless of selection.







# Select command

 Synchronization starts; when complete, details appear.



# *OK* **⇒** Synchronization complete

**Canceling Synchronization** 

# Wi-Fi

# General

Disabling Wi-Fi	MENU → Tools → Connectivity tab → Wi-Fi → Switch On/Off → Off  • Set to Off when not using Wi-Fi to extend Battery Time.
Showing confirmation when switching networks	MENU → Tools → Connectivity tab → Wi-Fi → Common Settings → Switch Notification → Switch from 3G to Wi-Fi or Switch from Wi-Fi to 3G → On
Protecting access point information by Handset Code	MENU → Tools → Connectivity tab → Wi-Fi → Common Settings → Handset Code Lock Setting → On → Enter Handset Code → OK
Specifying channel range	MENU → Tools → Connectivity tab → Wi-Fi → Common Settings → Channel Range → Select range  • In some countries, there are restrictions on available channels. Select channel range accordingly while outside Japan.
Opening access point properties	MENU → Tools → Connectivity tab → Wi-Fi → Connect Information
Opening Wi-Fi-related handset properties	MENU → Tools → Connectivity tab → Wi-Fi → Show MAC Address

# ■ Managing Access Points

Managing registered access points	Start Here MENU → Tools → Connectivity tab → Wi-Fi → Profile List → Highlight access point → Options → See below
	Changing Priority  Change Priority   Select target location   Accept
	Editing  Edit → Complete fields → Save
	Deleting Delete → Yes

# ■ Advanced Settings

When finished with Advanced Settings, complete other fields to register an access point.

	Start Here MENU → Tools → Connectivity tab → Wi-Fi → Create Profile → Manual → Advanced Settings → IP Settings → IP Address → Manual → See below
etting IP address	Entering IP Address  IP Address   Enter numbers   Accept   OK
	Entering Subnet Mask  Subnet Mask   Enter numbers   Accept   OK
	Entering Default Gateway  Default Gateway   Enter numbers   Accept  OK



Setting DNS server addresses	Start Here MENU → Tools → Connectivity tab → Wi-Fi → Create Profile → Manual → Advanced Settings → IP Settings → DNS Server Address → Manual → See below	
	Entering Primary DNS  Primary DNS ⇒ Enter numbers ⇒ Accept ⇒ OK	
		Entering Secondary DNS Secondary DNS → Enter numbers → Accept → OK
	Disabling Wi-Fi when using Yahoo! Keitai/PC Site Browser	MENU → Tools → Connectivity tab → Wi-Fi → Create Profile → Manual → Advanced Settings → Yahoo! Keitai Use Setting → Not Use → OK

# Infrared

Sending My Details	MENU → Phone → My Details → Options → Send My Card → Via Infrared → Yes → Transfer starts
Sending non-Phone Book files	In file list, highlight file   Options   Send (or Send/Blog)   Via Infrared   Yes   Transfer starts
Sending images via IrSS Transfer without reducing size	MENU → Tools → Connectivity tab → Infrared → IrSS Key Setting → Send via IrSS

# IC Transmission

Disabling one file reception	MENU → Tools → Connectivity tab → IC Transmission → 1 File Reception → Off(Disabled)	
Sending My Details	MENU → Phone → My Details → Options → Send My Card → Via IC Transmission → Yes → Transfer starts	
Sending non-Phone Book files	In file list, highlight file   Options   Send (or Send/Blog)   Via IC Transmission   Yes   Transfer starts	

# Bluetooth®

# ■ General

Cloaking handset to avoid connection requests	MENU → Tools → Connectivity tab → Bluetooth → My Device Settings → Visibility → Hide My Phone
Setting idle time after which Bluetooth® is canceled	MENU ⇒ Tools ⇒ Connectivity tab ⇒ Bluetooth ⇒ My Device Settings ⇒ Bluetooth Timeout ⇒ Select time
Switching audio output to wireless device	MENU → Tools → Connectivity tab → Bluetooth → My Device Settings → ③ Sound Output → Bluetooth Device • Bluetooth Device is set automatically when connection is made from wireless Headphones.
Changing Bluetooth® name for handset	MENU → Tools → Connectivity tab → Bluetooth → My Device Settings → Device Name → Enter name → Done
Talking on handsfree device	MENU ⇒ Tools ⇒ Connectivity tab ⇒ Bluetooth ⇒ My Device Settings ⇒ Handsfree Setting ⇒ Handsfree Mode



Avoiding connection requests from Bluetooth®-compatible S! Applications in Standby, etc.	MENU → Tools → Connectivity tab → Bluetooth → My Device Settings → S! Appli Request → Off
Receiving connection requests while connected to a device	MENU → Tools → Connectivity tab → Bluetooth → My Device Settings → Plural Connect Standby → On
Opening Bluetooth®-related handset properties	MENU → Tools → Connectivity tab → Bluetooth → My Device Details • Tap Help to view service details.

# ■ Bluetooth® Watches

Synchronizing Bluetooth® watch with handset	MENU → Tools → Connectivity tab → Bluetooth → Setting Watch → Set BT-Watch Time → Yes  • Connect handset to a Bluetooth® watch beforehand.
Enabling/disabling Bluetooth® watch responses	MENU → Tools → Connectivity tab → Bluetooth → Setting Watch → Notification → Select item → Permit or Prohibit  • Begister a Bluetooth® watch beforehand

# ■ Paired Devices

Editing Paired Device list	Start Here MENU ⇒ Tools ⇒ Connectivity tab ⇒ Bluetooth ⇒ Paired Devices ⇒ Highlight device ⇒ Options ⇒ See below
	Renaming Paired Devices  Change Name → Enter name → Done
	Deleting Paired Devices  Delete → Yes  To delete a device connected to handset, tap Yes.
Disconnecting devices	MENU → Tools → Connectivity tab → Bluetooth → Paired Devices → Select connected device
Connecting devices supporting handsfree telephony and audio output by service	MENU → Tools → Connectivity tab → Bluetooth → Paired Devices → Highlight device → Options → Select Service → Handsfree function or Audio function
	Start Here MENU → Tools → Connectivity tab → Bluetooth → Paired Devices → Highlight device → Options → Set to Prior Connect → See below
Specifying a preferred device for wireless connection	For Handsfree Telephony Handsfree On For Handsfree On, specified device reconnects to handset when placing/receiving calls.
	For Audio Output Audio On  ■ For Audio On, Media Player/TV audio output is redirected to specified device automatically when  Sound Output is set to Bluetooth Device.



# ■ Sending Files

Sending My Details	MENU → Phone → My Details → Options → Send My Card → Via Bluetooth → Select device → Yes → Transfer starts
Sending non-Phone Book files	In file list, highlight file → Options → Send (or Send/Blog) → Via Bluetooth → Select device → Yes → Transfer starts

# Backup

# ■ Backup & Restore

Backing up all items	MENU → Settings → Phone/  tab → Backup/ Restore → Backup All Items → Enter Handset Code → OK → Yes → Yes → Backup complete → OK → OK
Encoding data for backup	MENU → Settings → Phone/ □ tab → Backup/ Restore → Settings/Manage → Encode Settings → Select item → On  • Available for Phone Book, Messaging folders, Calendar and Tasks.
Restoring all items	MENU → Settings → Phone/ □ tab → Backup/ Restore → Restore All Items → Enter Handset Code → OK → Yes → Yes → Restore complete → OK → OK

# ■ Backup Files

	MENU ⇒ Settings ⇒ Phone/ tab ⇒ Backup/
Deleting backup	Restore > Settings/Manage > File Management
files	Select item ⇒ Select file ( /√) ⇒ Complete
	selection ⇒ Delete ⇒ Yes

S! Addressbook Back-up	
Canceling auto synchronization	MENU → Phone → S! Addressbook Back-up → Details → Auto Sync Settings → Set On/Off → Off
	Start Here MENU → Phone → S! Addressbook  Back-up → Details → Auto Sync Settings →  See below  • Set Set On/Off to On beforehand.
Changing auto synchronization settings	Auto Sync Frequency  Set Frequency → Select frequency → Enter/ select date/time/day of the week → Accept  For After Editing Ph.Book(10 min.), omit steps for date, time, etc.
	Auto Sync Command  Sync Mode Setting   Select command
Confirming password	Y! ⇒ メニューリスト ⇒ My SoftBank ⇒ English ⇒ Password confirmation for S! Address Book • Follow onscreen instructions.
Opening log	MENU → Phone → S! Addressbook Back-up → Details → Sync Log → Select record
	Start Here MENU → Phone → S! Addressbook  Back-up → Details → Sync Log → See below
Deleting log records	One Record Highlight record ⇒ Options ⇒ Delete ⇒ Yes
	All Records  Options   Delete All   Yes



#### Wi-Fi



#### Wi-Fi disconnects

 Connection is interrupted automatically if Display goes dark after a period of inactivity: restored when Display reactivates.



#### Cannot connect to Wi-Fi

• Depending on access point settings, handset may not connect to Wi-Fi when powered on outside 3G range. In this case, pass through the 3G service area carrying the handset and retry.



#### Login page opens when using public wireless LAN service

 Some public wireless LAN services require authentication via Direct Browser. Enter corresponding user ID/ password.

#### File Transfer



#### Some files are not received

• If storage limit is reached during transfers, remaining files will not be received



#### Cannot receive/accept connection requests even when Infrared/ Bluetooth® is On

- · Handset may not be in Standby.
- Keypad Lock/Function Lock may be active
- Software Update may be in progress.



# Phone Book settings are lost

- One file transfer resets these settings:
- Category, Tone/Video, Light, Vibration, Secret
- · Picture setting may be lost depending on image; send the image separately and reassign it.



# Calendar/Tasks settings are lost

- One file transfer resets these settings:
  - Alarm Tone/Video, Secret. S! Friend's Status



#### Bookmarks are not saved properly

- · Large Bookmarks may not be received correctly.
- · Streaming Bookmarks are saved as Yahoo! Keitai Bookmarks.



#### Messages are not saved properly on handset

- Messages may not be received depending on the size.
- Messages received via One File Transfer are saved to Other Documents folder and cannot be used as messages.
- Sky Mail may be received as S! Mail when transferred from other SoftBank handsets via All File Transfer
- In All File Transfers, overwriting messaging folders deletes sort keys.



#### Messages are not saved properly on recipient devices

- Mail Notices are saved as messages, invalidating complete message retrieval.
- When sending messages to other handset models via All File Transfer. Spam Folder messages may be saved to the incoming message folder.
- When sending messages in Drafts to other handset models via All File Transfer, only the first entered recipient may remain or SMS addressed to multiple recipients may not be saved



#### Cannot find files in DCIM folder

· Received files in DCIM folder are saved to Pictures folder



#### Infrared



# Infrared transfer fails

- . Infrared Port may be obstructed by dust, etc.; clean with soft cloth.
- Transfers may fail in direct sunlight. under fluorescent lighting or near infrared equipment.

#### **Backup & Restore**



#### Backup fails

 Check handset/Memory Card memory; backup may fail if the memory is low.



#### Some files are not restored

· If storage limit is reached during Restore, remaining files will not be restored



#### Cannot use backup files on other SoftBank handsets or PCs

• Some backup files may not be usable on other SoftBank handsets or PCs.



# Cannot open backup files

 Some backup files may open only after being restored to handset.



# Phone Book settings are lost

• Picture setting may be lost depending on image; send the image separately and reassign it.



#### Messages are not saved properly

- Transfer may delete sort keys.
- Mail Notices are restored as messages, invalidating complete message retrieval.



#### Bookmarks are not saved properly

- Yahoo! Keitai, Streaming and PC Site Browser/Direct Browser Bookmarks are all backed up as a single file.
- · Streaming Bookmarks are saved as Yahoo! Keitai Bookmarks.

#### Exporting Backed Up Data to Other SoftBank Handsets



# Messages are not saved properly

- If spam filter is available on recipient handset, Spam Folder messages are saved in spam folder regardless of the setting. (If unavailable, they are saved as normal received messages.)
- When restoring draft messages, only the first entered recipient may remain or SMS addressed to multiple recipients may not be saved.

#### Importing Data Backed Up on Other SoftBank Handsets



# Messages are not saved properly

- · Messages may not be restored depending on the size.
- Sky Mail may be restored as S! Mail.

